




FROM THE
#1
author
IN PC
HARDWARE

BIGELOW'S

DRIVE & MEMORY Troubleshooting Pocket Reference

Stephen J. Bigelow

The complete guide for diagnosing and solving PC drive and memory problems

If you're in need of answers when a malfunction occurs in your PC's storage system, then look no further than *Bigelow's Drive and Memory Troubleshooting Pocket Reference*. Inside this handy reference you'll find information about the newest memory technologies along with helpful tips and techniques for selecting, installing, optimizing, and troubleshooting which are applicable to all PC computer systems.

Written by best-selling author and computer professional, Stephen Bigelow, the book is filled with the practical advice you've come to expect to quickly solve PC problems. It provides all the know-how needed to:

- Understand, select, install, and troubleshoot PC memory
- Install hard drives of any size into almost any system without losing data
- Maintain peak hard drive performance
- Optimize your CD-ROM, CD-R, and CD-RW drive performance
- Master DVD-ROM drive installation and troubleshooting
- Keep your tape drives running reliably
- Overcome PC card conflicts and problems

Packed with step-by-step troubleshooting procedures, this is the most accessible one-stop guide available for PC techs, end users, and enthusiasts alike!

Series Design: Tisa Lynn Lerner Photomontage: Eric Yang

Computing

Mc
Graw
Hill

REQUIRED READING

\$19.99 USA

www.osborne.com



6 39785 31599 5

ISBN 0-07-135453-0



9 780071 354530

90000



Contents

List of Symptoms	xiii
------------------	------

Section 1. Memory Modules	1
Memory Types	2
BEDO (Burst Extended Data Output RAM)	2
CDRAM (Cached DRAM)	2
DDR SDRAM (Double Data Rate SDRAM)	2
DRAM (Dynamic Random-Access Memory)	3
EDO RAM (Extended Data Out RAM)	4
EDRAM (Enhanced DRAM)	4
FPM DRAM (Fast-Page-Mode DRAM)	5
PC100 SDRAM	5
RDRAM (Rambus DRAM)	6
SDRAM (Synchronous or Synchronized DRAM)	7
SRAM (Static Random-Access Memory)	7
VRAM (Video Random-Access Memory)	8
WRAM (Windows RAM)	9
Memory Characteristics	9
Memory speed and wait states	10
Determining memory speed	11
Megabytes and memory layout	12
Presence detect (PD)	14
Understanding memory refresh	14
Memory techniques	20
Composite vs. noncomposite	22
Parity and Error Correction	23
The parity principle	23

vi	Contents	Contents	vii
	Even vs. odd		23
	The problems with parity		24
	Circumventing parity		24
	Abuse and detection of fake-parity memory		25
	Alternative error correction		27
	Memory Organization		28
	Conventional memory		28
	Extended memory		30
	Expanded memory		31
	Upper memory area		32
	High memory		33
	Selecting and Installing Memory in PCs		33
	Getting the right amount		34
	Filling banks		35
	Bank requirements		35
	Selecting and Completing BIOS Upgrades		37
	Recognizing BIOS problems		40
	Gathering information		44
	Determining BIOS IC type		45
	Updating a flash BIOS		46
	Memory Troubleshooting		48
	Repairing SIMM/DIMM sockets		49
	Contact corrosion		50
	Parity errors		50
	Traditional AT memory errors		51
	Contemporary memory symptoms		52
	BIOS upgrade troubleshooting		60
	Windows-related memory errors		65
	Web Contacts		79
	Section 2. Floppy Drives		81
	Floppy Drive Layout and Characteristics		81
	Drive sensors and electronics		83
	Physical interface		86
	Floppy Drive Installation and Replacement		89
	Typical installation		90
	Reversing floppy drive assignments		95
	Floppy Drive Troubleshooting		97
	Floppy troubleshooting guidelines under Windows 95/98		97
	Symptoms		100
	Web Contacts		113
	Section 3. LS-120 Drives		115
	LS-120 Drive Layout and Characteristics		115
	Diskette compatibility and cleaning		116
	LS-120 Drive Installation and Replacement		117
	Typical installation		119
	Driver installation		122
	LS-120 Considerations and Issues		125
	Bootting and system BIOS		125
	Bootting and operating systems		126
	Compatibility with system manufacturers		126
	Compatibility with system utilities		127
	LS-120 device conflicts		127
	Drive overlay software		128
	Driver support under Windows 95A		129
	LS-120 Troubleshooting		129
	Web Contacts		140
	Section 4. Iomega Zip Drives		141
	Zip Drive Installation and Replacement		142
	Parallel port		142
	USB port		143
	ATAPI IDE port		144
	Getting the most from your Zip drive		148
	Zip disk guidelines		150
	Zip Drive Software Considerations and Testing		151
	Obtaining updated Zip software		152
	Manually installing Zip parallel-port drivers		152
	Uninstalling Zip software		154
	Changing the Zip drive letter		154
	Formatting Zip disks with Iomega software		155
	Formatting Zip disks with Windows 95/98 FORMAT		155
	Formatting Zip disks with DOS		155
	Protecting Zip disks		156
	Zip drive troubleshooting		156
	Web Contacts		193
	Section 5. Hard Drives		195
	IDE/EIDE Hard Drive Concepts		196
	Binary megabytes vs. decimal megabytes		196
	IDE/ATA		197

viii	Contents	Contents	ix
	ATAPI		198
	ATA-2, Fast-ATA, and EIDE		198
	ATA-3		199
	Ultra-ATA/33		199
	Ultra-ATA/66		200
	Common UDMA/66 issues		200
	Data transfer rates		201
	Block mode transfers		203
	Ideas of bus mastering		204
	Concepts of Drive Formatting		207
	Low-level formatting		208
	Partitioning		210
	High-level (DOS) formatting		211
	File Systems and Tips		212
	FAT basics		212
	FAT16		213
	Positioning a large hard drive with FAT 16 FDISK		214
	Partitioning large hard drives		214
	FAT32		216
	Partitioning and formatting for FAT32		217
	Using the FAT32 drive converter		220
	Creating a FAT32 Startup Disk for Windows 98		221
	Understanding the master boot record		222
	Understanding Drive Capacity Limits		224
	Cylinder limits in BIOS		225
	Partition limits in the operating system		225
	Overcoming capacity limits		226
	Hard Drive Installation/Replacement Guidelines		229
	Select jumper configurations		229
	Attach cables and mount the drive		230
	Configure the CMOS Setup		231
	Finish the drive preparation		232
	Reassemble the computer		232
	Drive Testing and Troubleshooting		232
	General troubleshooting guidelines		233
	Potential problems with Y splitters		234
	Potential problems with bus speeds beyond 66 MHz		235
	Troubleshooting DOS compatibility-mode problems		236
	Detecting a DDO		240
	Removing a DDO		241
	Hardware symptoms		242
	File system symptoms		263
	Software-oriented symptoms		267
	FAT32 symptoms		279
	Web Contacts		290
	Section 6. CD-ROM Drives		293
	Understanding CD Media		294
	CD data		294
	Caring for compact disks		296
	CD-ROM/CD-R Standards and Characteristics		297
	High Sierra		298
	ISO 9660		298
	CD-ROM/CD-R standards ("books")		299
	The multispin drive		300
	The MPC		301
	Effects of CD-ROM caching		301
	Bootable CD-ROM (El Torito)		303
	CD-ROM Installation and Replacement		304
	Select jumper configurations		304
	Attach cables and mount the drive		305
	Configure the CMOS Setup		306
	Reassemble the computer		306
	Install the software		306
	Understanding the Software		307
	Device drivers		307
	MSCDEX.EXE		308
	Troubleshooting CD-ROM Drives		310
	General symptoms		311
	Windows-related symptoms		326
	Web Contacts		345
	Section 7. CD-R Drives		347
	Understanding CD-R Concepts		347
	"Orange Book certified" media		348
	Multisession CDs		348
	Fixation vs. finalization		349
	Disk-at-Once		349
	Track-at-Once		350
	Incremental and packet writing		350
	Caring for recordable CDs		350
	CD-R Installation and Replacement		351
	Select jumper configurations		352
	Attach cables and mount the drive		352
	Configure the CMOS Setup		353

x	Contents		Contents	xi
	Reassemble the computer	354	Section 9. DVD-ROM Drives	415
	Install the software	354	The Potential of DVD	415
	Understanding the Software	355	Specifications and Standards	417
	Device drivers	355	Access time	417
	MSCDEX.EXE	356	Data transfer rates	418
	Upgrading CD-R firmware	358	Books and standards	418
	Troubleshooting CD-R drives	359	Data formats	419
	CD recording issues	359	Audio and video standards	419
	Typical compatibility problems	362	Region code control	420
	Typical multisession CD issues	364	CD compatibility	421
	Buffer underruns	365	Caring for a DVD disk	421
	General CD-R symptoms	370	The MPEG-2 Decoder Board	422
	Web Contacts	385	A look at MPEG-2	423
			Notes on Dolby AC-3	423
			Decoder board connections	424
			Software DVD decoders	425
			DVD-ROM installation and replacement	426
			Select jumper configurations	427
			Attach cables and mount the drive	427
			Install the decoder card	428
			Configuring the CMOS Setup	429
			Reassemble the computer	429
			Install the software	429
			Upgrading DVD-ROM firmware	430
			Troubleshooting DVD-ROM drives	431
			Initial setup and tips	431
			DVD software and Windows 98	432
			Installation and startup symptoms	434
			Performance/operating symptoms	443
			Windows-related symptoms	452
			Web Contacts	459
	Section 8. CD-RW Drives	387	Section 10. Removable Media Drives	461
	Understanding CD-RW Concepts	388	General Drive Installation and Replacement	462
	Working with UDF	389	Select jumper configurations	462
	Disk capacity under UDF	389	Preinstall any software	463
	UDF and disk compatibility	389	Attach cables and mount the drive	463
	Multi-Read CD-ROM drives	390	Configure the CMOS Setup	464
	UDF readers	391	Reassemble the computer	464
	UDF reader compliance	391	Install the software	465
	UDF and audio CDs	392	Iomega Bernoulli and Jaz Drives	465
	Windows 98 and UDF	392		
	Using DirectCD	392		
	Preparing a data CD	393		
	Writing data to a DirectCD disk	394		
	Ejecting a DirectCD disk	394		
	Erasing a DirectCD disk	394		
	Fixing an unreadable disk	395		
	Caring for rewritable CDs	395		
	CD-RW Installation and Replacement	397		
	Select jumper configurations	397		
	Attach cables and mount the drive	398		
	Configuring the CMOS Setup	399		
	Reassemble the computer	400		
	Install the software	400		
	Upgrading CD-RW firmware	400		
	Troubleshooting CD-RW Drives	401		
	Troubleshooting tips	402		
	General symptoms	402		
	Web Contacts	413		

Read/write-protecting Jaz disks	466
Unprotecting the Jaz software disk	467
Removing Iomega Tools from the Startup group	468
Uninstalling Jaz Tools software	468
Bernoulli drive troubleshooting	469
Jaz/Bernoulli adapter troubleshooting	474
Jaz drive troubleshooting	481
SyQuest EZ-Flyer and SyJet Drives	496
Ejecting a "powered" SyQuest cartridge	498
Ejecting an "unpowered" SyQuest cartridge	499
SyQuest drive and cartridge tips	499
General SyQuest drive tips	500
SyQuest drive troubleshooting	502
Web Contacts	521
 Index	 523